

# INSTALLATION GUIDELINES

## Synergy<sup>®</sup> MPL



### *Strand Bamboo Solid-Strip 12mm Flooring with Xcora™ Technology*

#### **Important Product Line Notes:**

- Check Teragren.com for the latest updates to our Installation Guidelines
- Teragren Synergy Strand Bamboo Solid-Strip Flooring is suitable for installation as a glue-down or nail-down system on or above grade. Use only adhesives certified by their manufacturer for use with Teragren Strand Bamboo. Do not use staples. Only use 18 gauge cleats.
- Acclimation: Teragren Synergy Strand Bamboo Solid-Strip Flooring should be delivered to the job site no less than 72 hours prior to installation. Flooring should be removed from its packaging and be allowed to acclimate to the relative humidity conditions expected to be present on an ongoing basis. Please see section on Product Acclimation.
- Ensure flooring is installed to allow for up to 1/2" expansion or contraction around perimeter
- Teragren Bamboo Flooring may be installed over radiant floor heating systems (see "Radiant Floors" section below). Surface Temperature of flooring should never exceed 85° F
- The use of Vapor Barriers (over cementitious materials) or Vapor Retarders (over wood) is mandatory
- Installer to document installation date, product run code (off box ends), flooring moisture content, site relative humidity, site temperature, and subfloor moisture content. This information should be retained by the installer and left with the property owner as a permanent record.

#### **Pre-Installation Notes:**

Please read Teragren LLC's warranty, maintenance instructions, and **ALL** of the following guidelines before opening any packaging or beginning your flooring installation. All information within this document is provided as a courtesy to our customers and is meant to be understood as an installation guideline only. The customer and/or the installer is solely responsible for any and all decisions regarding how, where, and when to install any Teragren product.


Teragren LLC recommends using the services of a professional hardwood flooring installer. For more information and for guidelines on the installation of hardwood flooring, please contact the National Wood Flooring Association or review their website <http://www.woodfloors.org>.

Because bamboo is a natural fiber, it is not uncommon for natural variations in color to occur within and between individual flooring planks. Teragren's warranty does not cover variations in color either in individual planks, between the planks, or the variations in color between our product samples and the installed flooring. An industry standard of 5% material overage should be added to the actual square footage required for cutting and grading allowances.

Prior to installation, all material must be inspected to ensure the material received matches the work order. Any visible defects or discrepancies should immediately be reported to your distributor or dealer. It is considered the installer/owner's responsibility not to install flooring having finish, manufacturing, or unacceptable material variations. Individual planks with defects should not be installed or the defect should be cut-out prior to installation. Filler or putty sticks may be used to correct minor flooring defects during installation. The Teragren warranty does not cover materials with visible defects once they are installed. **Installation of any Teragren product serves as acceptance of that material.**

**Unexpected changes to subfloor moisture content or changes to Relative Humidity outside of the approved range of 35-55% may cause bamboo flooring to gap, cup, buckle, or otherwise dimensionally change. Bamboo Flooring must be installed into a relative humidity controlled environment over a moisture barrier or vapor retarder (see Sub-Floors section below) per the following specifications:**

- **Concrete Subfloors:** Use an appropriate liquid or trowel-applied moisture barrier membrane/adhesive system. Impermeable moisture barrier systems with a perm rating less than or equal to .13 are suggested.
- **Wood Subfloors:** Use a UU-B-790a, Grade B, Type 1, Style 1a permeable vapor retarder or equivalent with a perm rating between .7 and 1



**NOTE: Flooring must be installed in such a manner to allow for up to 1/2" expansion and 1/2" contraction of your installed flooring.** Bamboo, like all hardwoods, expands and contracts as its moisture content rises and falls.

Use a combination of wall moldings such as a base-molding and base-shoe together to ensure that the edge of the installed flooring does not strike the wall if it expands and does not show if the flooring shrinks.

**It is the sole responsibility of the installer/owner to determine if the job site's sub-floor and environmental conditions are suitable for the installation of Teragren flooring and accessories. Teragren LLC makes no warranty or guarantee of the quality of the chosen installer's work or of a particular installation performed by the installer. Teragren LLC disclaims all liability for any errors or improprieties in the installation of its products.**

**Product Acclimation:**

Open each box, remove the flooring from its packaging, and stack the flooring planks at least 4" off the ground (with stickers between each layer of planks) to allow for complete and even air-circulation around the flooring.

Acclimation should occur at the room temperature expected to be present before, during, and after installation. For maximum material stability, Bamboo Flooring must be installed into environments with relative humidity (RH) and temperature controls capable of maintaining the delivered moisture content of 7-9%. Please reference the following chart for correlations between RH, Temperature, and moisture content (%):

**\* Relative Humidity levels required to maintain below moisture content:**

RH		5%	10%	15%	20%	25%	30%	35%	40%	45%	50%	55%	60%	65%	70%	75%	80%	85%	90%	95%	
° F	° C	<b>Moisture content (%) of wood at above relative humidity values:</b>																			
30°	-1.1°	1.4	2.6	3.7	4.6	5.5	6.3	7.1	7.9	8.7	9.5	10.4	11.3	12.4	13.5	14.9	16.5	18.5	21.0	24.3	
40°	4.4°	1.4	2.6	3.7	4.6	5.5	6.3	7.1	7.9	8.7	9.5	10.4	11.3	12.3	13.5	14.9	16.5	18.5	21.0	24.3	
50°	10.0°	1.4	2.6	3.6	4.6	5.5	6.3	7.1	7.9	8.7	9.5	10.3	11.2	12.3	13.4	14.8	16.4	18.4	20.9	24.3	
60°	15.6°	1.3	2.5	3.6	4.6	5.4	6.2	7.0	7.8	8.6	9.4	10.2	11.1	12.1	13.3	14.6	16.2	18.2	20.7	24.1	
70°	21.1°	1.3	2.5	3.5	4.5	5.4	6.2	6.9	7.7	8.5	9.2	10.1	11.0	12.0	13.1	14.4	16.0	17.9	20.5	23.9	
80°	26.7°	1.3	2.4	3.5	4.4	5.3	6.1	6.8	7.6	8.3	9.1	9.9	10.8	11.7	12.9	14.2	15.7	17.7	20.2	23.6	
90°	32.2°	1.2	2.3	3.4	4.3	5.1	5.9	6.7	7.4	8.1	8.9	9.7	10.5	11.5	12.6	13.9	15.4	17.3	19.8	23.3	
100°	37.8°	1.2	2.3	3.3	4.2	5.0	5.8	6.5	7.2	7.9	8.7	9.5	10.3	11.2	12.3	13.6	15.1	17.0	19.5	22.9	
110°	43.3°	1.1	2.2	3.2	4.0	4.9	5.6	6.3	7.0	7.7	8.4	9.2	10.0	11.0	12.0	13.2	14.7	16.6	19.1	22.4	
120°	48.9°	1.1	2.1	3.0	3.9	4.7	5.4	6.1	6.8	7.5	8.2	8.9	9.7	10.6	11.7	12.9	14.4	16.2	18.6	22.0	

From the U.S. Dept. of Agriculture "Wood Handbook — Wood as an Engineering Material" Section 3-7

Teragren 12mm Synergy Strand Bamboo Flooring is best installed by nailing or gluing planks to a wooden sub-floor, or by gluing flooring to a concrete subfloor. Do not install Synergy Strand Bamboo Solid-Strip flooring below grade.

**Tools Recommended (not all tools may be required):**

**Nail or Staple Installation:** Hammer (1 lb), tape measure, chalk line, pencil, carpenter square, scribing block, flat bar, 1/2" (12.5mm) wedges, saw, chop saw with 80 tooth carbide tipped blade, vapor retarder (wooden subfloor), pneumatic tongue & groove flooring nailer or manual nailer, 18 gauge cleat nails or equivalent (see appropriate section below). Note: Nail gauges larger than 18 gauge (e.g. such as 15.5 gauge) will damage 12mm Synergy Strand Bamboo Solid-Strip flooring.

**Glue Down Installation:** Calcium chloride or equivalent testing system, moisture barrier (concrete subfloor) or vapor retarder (wooden subfloor), premium wood flooring adhesive/moisture barrier system, hammer (1 lb), tape measure, chalk line, pencil, carpenter square, scribing block, flat bar, 1/2" (12mm) wedges, saw, chop saw with 80 tooth carbide tipped blade, low adhesive painter's tape.

### **Sub-Floor Examination and Preparation:**

A moisture barrier such as 6 mil polyethylene film should be placed in crawl spaces. Wood sub-flooring surfaces must have no flex and must be smooth, level, clean, dry, and free of contaminants. Fix any squeaks or movement in the sub-floor prior to flooring installation. The sub-floor surface must be level and smooth prior to flooring installation. Subfloors should be checked for flatness prior to installation and any low spots or voids should be filled to a minimum of 3/16" (4.76mm) within a 10' (3 meter) radius or 1/8" (3mm) in a 6' (1.8 meter) radius, and high spots ground to surface.

Acceptable sub-floor specifications include 5/8" (16mm) T&G CD Exposure 1 plywood for 12" (30.5cm) and 16" (41cm) on center floors (OC), 3/4" (19mm) T&G CD Exposure 1 plywood for 16" (40.6cm) to 19" (48.3cm) OC floors, and 7/8" (22mm) T&G CD Exposure 1 plywood for 24" (61cm) OC floors. A sub-floor of 1-1/8" (28.5mm) plywood over joists at 16" (40.6cm) on center is recommended for an optimal installation. Note: the use of particleboard may result in a substandard subfloor due to the lack of rigidity.

Concrete sub-floors MUST be tested for moisture in more than one place for consistent readings. Teragren recommends using a Calcium Chloride Test Method to quantify the volume of moisture vapor radiating from a concrete slab surface over time and / or a Relative Humidity Probe test to quantify the amount of relative humidity within the slab. The use of a Vapor Barrier (over cementitious materials) or a Vapor Retarder (over wood) is mandatory.

**Note:** Depending on the geographical area and interior climate control systems of the installation environment, to minimize expansion of nailed or glued-down floors that are wider than 20', installers may need to build-in additional spacing between planks and at the edge of rooms. Where additional spacing is required, use a removable spacer between every few rows of planks.

### **Nail or Staple-Down Installations:**

Teragren recommends the use of an 18 gauge cleat nailer and 1-1/4" to 1-1/2" cleat nails. The selection and use of any nailer is at the sole discretion and responsibility of the owner/installer. For a list of nailers tested by their manufacturer(s) as being compatible with Teragren flooring products, please visit [http://www.teragren.com/downloads/Teragren\\_Nailer\\_Guidelines.pdf](http://www.teragren.com/downloads/Teragren_Nailer_Guidelines.pdf).

**Note:** Nail gauges larger than 18 gauge (e.g. 15.5 gauge) will damage Synergy Strand Bamboo Solid-Strip flooring.

Install a moisture barrier or vapor retarder over the entire subfloor surface following closely the manufacturer's recommendations.

Due to the extreme hardness of Synergy Strand Bamboo Solid-Strip flooring, it is the responsibility of the installer to determine the correct pressure/psi for their nailer for their unique installation environment. Test nail a sacrificial plank to the sub-floor to check for correct air pressure, surface damage, tongue damage (splitting) etc. before proceeding with the installation.

Flooring should be square with the space and perpendicular to the joists. Leave a 1/2" (12.5mm) expansion space from base plate or wall. Starter rows shall be held firmly in place by gluing, wedging or blind nailing. Once starter rows are secure, additional rows shall be directly above the tongue at a 45-50 degree angle to the face.

Carefully monitor nailer pressure to ensure that the nail head enters the tongue only as deeply as required to allow the adjacent plank to fit properly. Ensure that the nail head rests cleanly in the "nail pocket". Nails shall be placed no closer than 3" from the ends of each plank and then spaced at 8" intervals or as required to prevent tongue splitting/damage.

### **Glue-Down Installations**

Install a moisture barrier. Teragren recommends the use of a low-VOC, premium, water-free flooring adhesive and/or moisture barrier system specifically recommended by the adhesive manufacturer for use with strand bamboo flooring. Note: Always use a moisture barrier and adhesive system manufactured by the same company – never mix products.

The sub-floor must be extremely flat (see adhesive manufacturer's specifications), be square with the space, and run perpendicular to the joists. Leave a 1/2" expansion space from base plate or wall. Starter rows should be held firmly in place

using wedges. Once the starter rows are secure, apply the adhesive per the manufacturers' installation instructions. NOTE: Always remove any adhesive from the surface of the flooring (smudges, fingerprints, etc.) before it dries. Clean up as you go – do not wait until the installation is complete. Cured adhesives are very difficult to remove and may permanently damage flooring. **Always follow the adhesive manufacturer's installation instructions.**

For a list of adhesives warranted by their manufacturer(s) as being compatible with Teragren flooring products, please visit [http://www.teragren.com/downloads/Teragren\\_Adhesive\\_Guidelines.pdf](http://www.teragren.com/downloads/Teragren_Adhesive_Guidelines.pdf)

It is up to the owner/installer to confirm the warranty, the environmental statements of the manufacturer, and the suitability of any adhesive for the intended end-use. The selection and use of any adhesive / moisture control system is at the sole discretion and responsibility of the owner/installer.

### **Radiant Heat:**

Teragren bamboo flooring is suitable for installation over radiant heating systems capable of maintaining a surface temperature at or below 85°F. When choosing an installer for application over radiant heat, look for members of the Radiant Panel Association. Please refer to [www.radiantpanelassociation.org](http://www.radiantpanelassociation.org) for more information on radiant heat systems.

Rugs placed on a floor heated by a radiant source can increase the surface temperature of that floor by 2-3 degrees Fahrenheit. If using an adhesive to "glue-down" bamboo flooring, please confirm with the adhesive manufacturer the suitability of the adhesive for use with radiant heating systems. Before installing the flooring, activate the radiant heating system and leave it on for at least 21 days prior to installation. Radiant heating systems must be turned off 24 hours prior to and during flooring installation. If no adhesive has been used, the radiant heating system may be reactivated after the flooring installation is complete. If adhesive has been used, follow the adhesive manufacturer's guidelines regarding adhesive cure time before reactivating the radiant heating system. Please refer to [www.radiantpanelassociation.org](http://www.radiantpanelassociation.org) for more information.

It is up to the owner/installer to confirm the suitability of any radiant-heating system for the intended end-use. The selection and use of any radiant heating system is at the sole discretion and responsibility of the owner/installer.

### **Maintenance Guidelines:**

Teragren recommends vacuuming or sweeping in order to remove dirt and grit prior to cleaning the flooring. Remove any liquid spills promptly. Exposure to the sun and ultra-violet light can accelerate oxidation (color-change). Periodically rearrange rugs and furniture to allow for consistent aging of the flooring. Use area rugs in high traffic areas. Install wood guards on the feet or legs of furniture.

Do not use wax, oil soap or other household cleaners. Teragren recommends using either WoodWise Floor Cleaner by Design Hardwood Products; 800.424.7092 or Bona Swedish Formula® Hardwood Floor Cleaner by BonaKemi USA, Inc. 800.574.4674. Use of some oil soaps or wax based cleaners may cause future difficulty when recoating flooring.

Proper care and maintenance can extend the life of your floor for many years; however, at some time a re-coat may be desirable. To re-coat your floor and remain in conformance with the Teragren warranty, follow the manufacturer's instructions at either of the following:

Basic Coatings TyKote® Dustfree Refinishing System [www.BasicCoatings.com](http://www.BasicCoatings.com) Toll-Free: 800. 441.1934  
or BonaPrep™ Re-coating Adhesion System by BonaKemi USA [www.bonakemi.com](http://www.bonakemi.com) Toll-Free: 800.872.5515.

[Basic Coatings TyKote® Dustfree Refinishing System](#) (800.441.1934) or [BonaPrep™ Re-coating Adhesion System](#) by [BonaKemi USA](#) (800.872.5515).

Contact your Teragren distributor or retailer for more information or [email tech support](#).

DISCLAIMER: Teragren LLC has provided this information "as is" without warranties of any kind, expressed or implied. Teragren LLC has made every reasonable effort to ensure the accuracy of the information provided in this document and is not responsible for any errors and/or omissions.



FINE BAMBOO FLOORING, PANELS & WORKTOPS